

Assembly Instructions

HyperGrip® Disposable Receptacle

June 2024



*Do Not Discard, Deliver to Manufacturing.
No Descartar, Entregar A Fabricación.
Instructions De Montage, Ne Pas Jeter.
Bitte nicht wegwerfen, bitte an die produktion weiter liefern.*

Assembly Instructions

Unshielded Disposable HG Receptacle Kits


Note: Components depicted in images are representative of HG2; Assembly of HG4 follows the same process

Crimp Termination Instructions

Step 1:


Strip wire

Insert into crimp barrel



Insert contact into positioner as shown


Crimp




OR Solder Termination Instructions

Step 1:

Strip wire




Solder wire into solder cup



Step 2


Insert contacts



Step 3


Push in to the stop

Insertion tool #T2080



Step 4

Install color coded panel seal
(optional)



Step 5

Panel seal installed



Step 6

Install nut



Worldwide Support

Connectors

Americas

Sales

connectors.uscsr@smithsinterconnect.com

Technical Support

connectors.ustechsupport@smithsinterconnect.com

Europe

Sales

connectors.emeacsr@smithsinterconnect.com

Technical Support

connectors.emeatechsupport@smithsinterconnect.com

Asia

Sales

asiacsr@smithsinterconnect.com

Technical Support

asiatechsupport@smithsinterconnect.com

Fiber Optics & RF Components

Americas

Sales

focom.uscsr@smithsinterconnect.com

Technical Support

focom.techsupport@smithsinterconnect.com

Europe

Sales

focom.emeacsr@smithsinterconnect.com

Technical Support

focom.techsupport@smithsinterconnect.com

Asia

Sales

focom.asiacsr@smithsinterconnect.com

Technical Support

focom.techsupport@smithsinterconnect.com

Semiconductor Test

Americas

Sales

semi.uscsr@smithsinterconnect.com

Technical Support

semi.techsupport@smithsinterconnect.com

Europe

Sales

semi.emeacsr@smithsinterconnect.com

Technical Support

semi.techsupport@smithsinterconnect.com

Asia

Sales

semi.asiacsr@smithsinterconnect.com

Technical Support

semi.techsupport@smithsinterconnect.com

RF/MW Subsystems

Americas, Europe & Asia

Sales

subsystems.csr@smithsinterconnect.com

Technical Support

subsystems.techsupport@smithsinterconnect.com

Connecting Global Markets

more > [smithsinterconnect.com](https://www.smithsinterconnect.com) | [in](#) [twitter](#) [youtube](#)